

COMPUTER INTERFACING TO AN NTC THERMISTOR



Using a precision NTC thermistor as a sensor for a uC or computer based instrument can be accomplished in a fairly straightforward manner. A thermistor/resistor voltage divider bridge can supply a strong signal to an A-D converter, which can then be interfaced to the desired instrument (Figure 1). Using the entire range of the thermistor (-55°C to 125°C), a 12 bit A-D can give a resolution of 0.04°C, a 10 bit 0.175°C and an 8 bit 0.70°C. Since an NTC thermistor exhibits a nonlinear change in resistance with a linear change in temperature, the voltage output of the bridge must be interpreted for the actual temperature. This can be accomplished with an R-T look up table, or through the use of an equation which characterizes the thermistor response.

APPLICATION USING AN R-T LOOK UP TABLE

Using this method, the A-D count is simply used as an offset to correlate to the temperature recorded in the table. The table is created by calculating or measuring the A-D count when the thermistor is at a given temperature or resistance value, and recording this in the table. This method has the advantage of the ability to manipulate the table to fit a particular thermistor's R-T characteristic very closely.

The following example uses a 10K ohm thermistor/10K ohm fixed resistor bridge network, and an 8 bit A-D converter.

R-T multiplier @ -55° C = 96.4 Thermistor R @ -55° C = 964K ohm Bridge voltage @ -55° C = 4.948V R-T multiplier @ 125^{\circ}C = .03461 Thermistor R @ 125^{\circ}C = 346.1 ohm Bridge voltage @ 125°C = 0.00048V R-T multiplier @ 25°C = 1 Thermistor R @ 25°C = 10K ohm Bridge voltage @ 25°C = 2.5V

Using these values, the A-D high ref would be set at 4.984V, and the low ref at 0.00048V, yielding (4.984V-0.00048V)/256 count or ~0.0194V per A-D count, giving the following:

A-D count at 125°C = 0000000, table element 0 = 125 A-D count at -55°C = 11111111, table element 255 = -55 A-D count at 25°C = 2.5V/0.0194V = 128.8dec = 10000001bin, table element 129 = 25

The in-between values are calculated in the same manner. The number of values in the table can be any power of 2 up to the resolution of the A-D converter. By dividing the A-D count by the appropriate number and using linear interpolation between the table entry numbers, required table memory space can be reduced with a minimum decrease in accuracy.

The following is an example in BASIC how to implement this using a 64 element lookup table and 8 bit A-D converter.

DIM TABLE (64) AS SINGLE TABLE (0) = 125	'this is the lookup table
•	
•	
	'this is ~129/4
TABLE $(32) = 25$	
•	
:	
TABLE (63) = -55	
•	
•	
•	
OPEN "A-D" FOR INPUT AS #1	'open A-D
INPUT #1, ADCOUNT	'and get count
TABLEOFFSET = INT(ADCOUNT/4)	'divide by 4 for lookup table of 64 elements. Round result to next lowest integer value.
TEMP = TABLE (TABLEOFFSET)	'get temperature at pointer
NEXTTEMP = TABLE (TABLEOFFSET+1)	'get temperature above pointer (next 'pointer location). Actual temperature is between these two.
DIFFTEMP = ABS (ADCOUNT-(TEMP*4))	'this is the distance from TEMP between TEMP and NEXTTEMP. This is the interpolated temperature. Remember that values in table decrease as the A-D count increases. Note that this assumes that a table point lies on 0. If there is no 0 entry separating positive and negative table entries, some
	additional conditions must be added to correctly interpolate.
INTERPTEMP = TEMP +	
(((TEMP-NEXTTEMP)/4)*DIFFTEMP)	
PRINT INTERPTEMP	'and the final output in degrees Celsius.

APPLICATION USING THERMISTOR CHARACTERIZATION EQUATION



Figure 1. (Left) A thermistor/resistor voltage divider bridge can supply a strong signal to an A-D converter, which can then be interfaced to the desired instrument.

a = ? b = ? c = ? d = ? resolution = 256 vref = 5 rfix = 10000 OPEN "A-D" FOR INPUT AS #1 INPUT #1, ADCOUNT VBRIDGE = ADCOUNT*(vref/resolution) RTHERM = VBRIDGE/((vref-VBRIDGE)/rfix)

'these constants need to be entered

'for 8 bit A-D
'bridge voltage
'fixed bridge resistor
'open A-D
'and get count
'convert to voltage across thermistor
'find thermistor resistance. Convert to temperature using given coefficients and equation. This is the standard Steinhart-Hart equation, with the 273.15 added to yield degrees Celsius.

$$\label{eq:temp} \begin{split} \mathsf{TEMP} &= (1/(a+b^*(\mathsf{InRTHERM})+c^*(\mathsf{InRTHERM})^2 + \\ &d^*(\mathsf{InRTHERM})^3)) - 273.15 \\ \mathsf{PRINT\,TEMP} \end{split}$$

'and the final output in deg C

ABOUT CTS CORPORATION

Founded in 1896, CTS Corporation (NYSE: CTS) is a leading designer and manufacturer of products that Sense, Connect, and Move. The company manufactures sensors, actuators, and electronic components in North America, Europe, and Asia. CTS provides solutions to OEMs in the aerospace, communications, defense, industrial, information technology, medical, and transportation markets. CTS focuses on providing advanced technology, exceptional customer service and superior value to industry partners throughout the globe.

CTS aims to be at the forefront of technology, delivering innovative sensing, connectivity and motion solutions for the creation and advancement of products and services around the world.

LEARN MORE

If you would like to learn more about how CTS can help you, please contact us today. We would be happy to discuss your project with you and help with the product selection process. Additionally, if you are unable to find the item you need, our engineers may be able to produce a custom component for your individual application.